OCTOGON

MANUAL

EILE

WEIGHT INDICATOR, LCD

Installation and user manual – Program Loading (C)



Document	Version	Date	Applies to
Installation and user manual	V00x	10/2026	EILE, Program Loading (C), versions P, Q, D, X

This manual describes installation, connection and operation of the EILE weight indicator with the load program (C): automatic loading of a settable product amount onto the scale through the PRESET and SET contacts, up to 99 formulas, fall, tolerance, consumption, analog output and serial protocols. The other programs and the approved (legal for trade) version have manuals of their own.

octogon GmbH · Roseggerstrasse 16 · 8700 Leoben · Austria · office@octogon.org

www.octogon.org

Contents

1 About this manual 4
1.1 Symbols 4
1.2 Scope 4
2 Safety, warranty and disposal 5
2.1 Recommendations for proper use 5
2.2 Recommendations for correct installation of the instrument 5
2.3 Maximum cable lengths 5
2.4 Warranty 5
2.5 Guidelines for proper disposal 5
3 Installation of the load cells 6
3.1 Sizing of load cell capacity 6
3.2 Installing load cells 6
3.3 Connecting several cells in parallel 6
3.4 Protection of the cell cable 6
3.5 Mechanical restraints (pipes, etc.) 6
3.6 Welding 6
3.7 Windy conditions, knocks, vibrations 6
3.8 Earthing the weighed structure 6
4 Load cell testing 7
4.1 Load cell input test (quick access) 7
4.2 Load cell resistance measurement (digital multimeter) 7
4.3 Load cell voltage measurement (digital multimeter) 7
5 Product description 7
5.1 Main specifications 7
5.2 Display 7
5.3 Versions and dimensions 8
5.4 Buffer battery 8
5.5 After a blackout 8
6 Technical specifications 8
6.1 UL version 9
7 Electrical connections 9
7.1 Basic information 9
7.2 Outputs, inputs and power supply 9
7.3 Terminals of versions P, Q and X 9
7.4 4-wire load cell 10
7.5 E/EC option 10
7.6 Connectors of version D 10
7.7 Changing voltage 115/230 VAC 11
8 Keys, display and menu map 11
8.1 Keys 11
8.2 Symbols of the LCD display 11
8.3 Formulas and batching constants menu 12
8.4 System parameters menu 12
9 Instrument commissioning 12
10 Calibration and weight parameters 13
10.1 Programming of system parameters 13
10.2 Theoretical calibration 13
10.3 Tare weight zero setting 13
10.4 Zero value manual entry 13
10.5 Real calibration (with sample weights) 14
10.6 Units of measure 14
11 Filter on the weight and zero parameters 15
11.1 Filter on the weight 15
11.2 Zero parameters 15
12 Outputs, inputs, alarm relay and test 15
12.1 Outputs 15
12.2 Inputs 15
12.3 Alarm relay closure 16
12.4 Test 16

13 Tare and zero 16
13.1 Semi-automatic tare (net/gross) 16
13.2 Preset tare (subtractive tare device) 16
13.3 Semi-automatic zero 17
14 Analog output (option) 17
15 Serial communication 17
15.1 Setting 17
15.2 Parameters 18
15.3 RS232 and RS485 18
15.4 Weight reading via serial port 18
15.5 WEIMOD and WEIRIP modes 18
16 Energy saving, date, operation settings and info 19
16.1 Energy saving 19
16.2 Date and time setting 19
16.3 Operation settings 19
16.4 Info menu 19
17 Batching constants 19
17.1 Minimum and maximum weight 20
17.2 Times 20
17.3 Fall 20
17.4 Tolerance 20
17.5 Slow and tapping function 20
17.6 Autotare 21
17.7 Consumption and printing 21
17.8 PC 21
17.9 ALARM and TOLERANCE relay on weight 21
18 Formulas 21
18.1 Formulas programming 21
18.2 Deleting formulas 21
19 Optional functions 22
19.1 Enabling optional functions 22
19.2 OPZWQMC – quantity greater than the scale capacity 22
19.3 OPZWLAUMAN – batching data on remote displays 22
20 Batching 22
20.1 Batching sequence 22
20.2 Batching start from external contact 23
20.3 Displaying during batching 23
20.4 Batching stop 23
20.5 Resume batching after a power cut 24
21 Consumption 24
21.1 Displaying consumption 24
21.2 Consumption deletion 24
22 Alarms 24
22.1 Serial protocol alarms 25
23 Printing examples 25
24 Reserved for the installer 27
24.1 Menu locking 27
24.2 Menu unlocking 27
24.3 Temporary menu unlocking 27
24.4 Setting unlock password 27
24.5 Data deletion and program selection 27
24.6 Keypad or display locking 28
25 Continuous transmission protocols 28
25.1 Continuous transmission to remote displays 28
25.2 Batching data to remote displays (OPZWLAUMAN) 28
25.3 Continuous transmission YHL 29
26 Modbus RTU protocol 29
26.1 Data format and functions 29
26.2 Broadcast requests and communication errors 29
26.3 List of available registers 30
26.4 Status, inputs, outputs, divisions 30
26.5 Commands to the command register 40006 32
26.6 Analog output 32
26.7 Real calibration commands 32

26.8 Constants and formulas reading and writing 33
26.9 Writing and reading formulas, batching start and stop 33
26.10 Batching data reading 33
26.11 Communication example 34
27 Directives and standards 34

1 About this manual

Display texts are set in a fixed-width typeface, as they appear on the display, for example **CALIb**. Keys are written in square brackets (section 8.1). A menu path is a sequence of keys and display texts, for example:

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[ENTER]** › **FS-tEO** › **[TARE] [PRINT]** › **UEIGHt**

000000 stands for the weight display. "[ENTER]+[ESC]" means: press [ENTER] immediately followed by [ESC]. "[TARE] [PRINT]" means: scroll to the next menu item with the arrow keys. In the menus changes are applied right after pressing [ENTER]; no further confirmation is required.

1.1 Symbols

Notice	Meaning
Caution	Risk of electric shock, or: this operation must be performed by skilled personnel.
Important	Pay particular attention to the following instructions.
Note	Further information.

1.2 Scope

The EILE is supplied with one of several programs; the instrument shows the program at switch-on (chapter 9). This manual applies to the load program (display **LOAd**): the instrument loads a settable amount of product onto the weighing structure automatically, driving the batching device (including two-speed) through the PRESET and SET contacts. It offers up to 99 formulas (chapter 18), batching resume after blackout (section 20.5), automatic fall calculation (section 17.3), autotare (section 17.6), tolerance error control (section 17.4), precision batching through slow or tapping function (section 17.5), consumption storage (chapter 21), print of batching data (chapter 23) and an alarm contact (section 12.3). Batching starts via keypad or via external contact (chapter 20); if an alarm occurs, the instrument shows it, closes the alarm contact (if enabled) and waits for the operator. The other programs have manuals of their own.

Of the options, this manual describes the analog output (chapter 14), the E/EC option (formula selection, section 7.5) and the optional functions of the program (chapter 19). Connection and setup of the other options of the data sheet – fieldbuses, WiFi, additional RS485, USB, external relay modules, alibi memory, weight inputs, data transfer to PC, battery – are provided by octogon on request.

2 Safety, warranty and disposal

2.1 Recommendations for proper use

- Keep away from heat sources and direct sunlight.
- Protect the instrument from rain (except special IP versions).
- Do not wash with water jets (except special IP versions).
- Do not dip in water.
- Do not spill liquid on the instrument.
- Do not use solvents to clean the instrument.
- Do not install in areas subject to explosion hazard (except special Atex versions).

2.2 Recommendations for correct installation of the instrument

- The terminals indicated on the instrument's wiring diagram to be connected to earth must have the same potential as the weighed structure (same earthing pit or earthing system). If this cannot be ensured, connect the terminals of the instrument (including the terminal –SUPPLY) to the weighed structure with an earthing wire.
- Lead the cell cable individually to its panel input, do not share a conduit with other cables, and connect it directly to the instrument terminal strip without breaking its route with support terminal strips.
- Use "RC" filters on the instrument-driven solenoid valve and remote control switch coils.
- Avoid inverters in the instrument panel; if inevitable, use special filters for the inverters and separate them with sheet metal partitions.
- The panel installer must provide electric protections for the instruments (fuses, door lock switch etc.).
- It is advisable to leave the equipment always switched on to prevent the formation of condensation.

2.3 Maximum cable lengths

Connection	Length
RS485	1000 m with AWG24, shielded and twisted cables
RS232	15 m for baud rates up to 19200
Analog current output	up to 500 m with 0.5 mm^2 cable
Analog voltage output	up to 300 m with 0.5 mm^2 cable

2.4 Warranty

24 months from the date of the delivery note. The warranty covers only failures of defective components (due to construction defects or defects in materials) and includes replacement or repair of the components and related labour costs.

The warranty is automatically forfeited in the event of:

- tampering, deletion, removal of the identification label and/or serial number of the product;
- misuse, transformation, alteration, repair of products not carried out by the manufacturer.

A 1-year warranty from the date of the delivery note applies to defects in material or manufacture of the battery.

2.5 Guidelines for proper disposal

- This is electrical/electronic equipment and cannot be disposed of as municipal solid waste, but must be delivered to a recycling centre.
- Improper use or disposal can pollute the environment or damage human health.
- Non-compliance with these guidelines will be penalised in accordance with the regulations in force in the country of destination.
- Dispose of the packing and packaging as required by local regulations.

3 Installation of the load cells

3.1 Sizing of load cell capacity

For safety reasons, in case of static weighing, it is advisable to use the load cells at a maximum of 70–80 % of their nominal capacity (assuming that the load is uniformly distributed over the entire weighed structure); depending on the handling mode of the load (e.g. forklifts, bridge cranes), consider reducing the share of the nominal capacity further. With dynamic loads the installer has to estimate thrust speed, acceleration, frequency, etc.

3.2 Installing load cells

The load cells must be placed on rigid, stable in-line structures; use the mounting modules for load cells to compensate for misalignment of the support surfaces.

3.3 Connecting several cells in parallel

Connect several cells in parallel by using – if necessary – a watertight junction box with terminal box. The cell extension cables must be shielded, led individually into their piping or conduit and laid as far as possible from the power cables (with 4-wire connections use cables of at least 4 × 1 mm^2).

3.4 Protection of the cell cable

Use water-proof sheaths and joints in order to protect the cell cables.

3.5 Mechanical restraints (pipes, etc.)

When pipes are present, use hoses and flexible couplings with open mouthpieces with rubber protection; with hard pipes, place the pipe support or anchor bracket as far as possible from the weighed structure (at a distance of at least 40 times the pipe diameter).

3.6 Welding

Avoid welding with the load cells already installed. If this cannot be avoided, place the welder ground clamp close to the welding point to prevent sending current through the load cell body.

3.7 Windy conditions, knocks, vibrations

The use of weigh modules is strongly recommended for all load cells to compensate for misalignment of the support surfaces. The system designer must ensure that the plant is protected against lateral shifting and tipping relating to: shocks and vibration; windy conditions; seismic conditions in the installation setting; stability of the support structure.

3.8 Earthing the weighed structure

By means of a copper wire with suitable cross-section, connect the upper support plate of each cell with its lower support plate, then connect all the lower plates to a single earthing system. Electrostatic charges accumulated by the product rubbing against the pipes and the container walls are discharged to the ground without going through or damaging the load cells. Without a proper earthing system the weighing system may still work, but future damage to the cells and the connected instrument cannot be ruled out. Earthing continuity must not be ensured by using metal parts of the weighed structure.

Important Failure to follow the installation recommendations will be considered a misuse of the equipment.

4 Load cell testing

4.1 Load cell input test (quick access)

Menu **000000** › **[PRINT] 3 s** › **MU-CEL**

From the weight display, press [PRINT] for 3 seconds: the response signal of the load cells is displayed, expressed in mV with four decimals.

4.2 Load cell resistance measurement (digital multimeter)

– Disconnect the load cells from the instrument and check that there is no moisture in the cell junction box caused by condensation or water infiltration. If so, drain the system or replace it if necessary.
– The value between the positive and the negative signal wire must be equal or similar to the output resistance indicated in the load cell data sheet.
– The value between the positive and the negative excitation wire must be equal or similar to the input resistance indicated in the load cell data sheet.
– The insulation value between the shield and any other cell wire and between any other cell wire and the body of the load cell must be higher than 20 MΩ.

4.3 Load cell voltage measurement (digital multimeter)

– Take out the load cell to be tested from underneath the container, or alternatively lift the container support.
– Make sure that the excitation of the two wires of the load cell connected to the instrument is 5 VDC ± 3 %.
– Measure the response signal between the positive and the negative signal wire by directly connecting them to the tester, and make sure that it is between 0 and ± 0.5 mV.
– Apply load to the cell and make sure that there is a signal increment.

Note If one of the above conditions is not met, please contact octogon.

5 Product description

5.1 Main specifications

Manufacturer type: WDESK-L

– Weight indicator with 6-wire load cell input, installable on table, front panel, wall or column
– 6-key keyboard
– Real-time clock/calendar with buffer battery
– Two serial ports (RS232 and RS485) for connection to: PC/PLC up to 32 instruments (max. 99 with line repeaters) by Modbus RTU protocol (section 15.1), remote display, printer
– Optional: integrated Profibus DP, DeviceNet, CANopen, Profinet IO, Ethernet/IP, Ethernet TCP/IP, Modbus TCP output

Versions P and D: switching power supply plug included, 24 V 450 mA, input 100 ... 240 VAC, 3 m cable. The instrument can be connected to an intelligent junction box (e.g. octogon ETLB) or to a weight transmitter.

Caution Version D is not compatible with the optional 115/230 VAC power supply.

5.2 Display

Display	Digit height	LED or symbols
backlit LCD, 6 digits, 7 segments, semi-alphanumeric	20 mm	max. 46 symbols

5.3 Versions and dimensions

Version	Max. encumbrance	Drilling
P – M16 × 1.5 cable glands · IP67 protection rating · power supply included	122 × 226 × 164 mm (connectors included)	96 × 186 mm
Q – removable terminal strip (panel front) · front panel IP67	122 × 226 × 152 mm (connectors included)	92 × 186 mm
D – D-Sub connector · IP40 protection rating, front panel IP67 · power supply included	122 × 226 × 189 mm (connectors included)	96 × 186 mm
X – Atex cable glands · Atex II 3GD (zones 2-22) · IP67 protection rating	122 × 226 × 164 mm (connectors included)	96 × 186 mm
Wall installation with bracket (can also be installed on table)	approx. 122 × 230 × 250 mm (bracket included)	–

The source gives the dimensions in the order height × width × depth.

5.4 Buffer battery

The instrument is equipped with an internal battery that keeps the internal clock running even in the event of power failure.

Important At the first start and after long periods of inactivity, leave the instrument on for at least 12 hours to fully charge the battery.

5.5 After a blackout

After a blackout the instrument does NOT come on again automatically; [ON/OFF] has to be pressed. To guarantee an automatic restart after a blackout, disable the ON key as follows:

- disconnect power supply and open the instrument;
- identify the flat connectors coming from the keypad on the main board;
- extract the 4-pole connector;
- short-circuit the two pins further in compared to the main board using the unused jumper inside the instrument;
- connect the 4-pole flat cable to the two pins still free, complying with the initial orientation.

6 Technical specifications

Item	Value
Power supply and consumption (VDC)	12/24 VDC ± 10 %; 6 W (standard)
Power supply and consumption (VAC)	115/230 VAC; 50–60 Hz; 6 VA (optional)
No. of load cells in parallel and supply	max. 8 (350 Ω); 5 VDC / 120 mA
Linearity / analog output linearity	< 0.01 % F.S.; < 0.01 % F.S.
Thermal drift / analog output thermal drift	< 0.0005 % F.S./°C; < 0.003 % F.S./°C
A/D converter	24 bit (16000000 points)
Max. divisions (measurement range ± 10 mV = sens. 2 mV/V)	± 999999
Measurement range	± 39 mV
Max. sensitivity of usable load cells	± 7 mV/V
Max. conversions per second	300
Display range	± 999999
No. of decimals / display increments	0 … 4 / x1 x2 x5 x10 x20 x50 x100
Digital filter / readings per second	10 levels / 5 … 300 Hz
Relay outputs	5 – max. 115 VAC; 150 mA (4 with analog output)
Digital inputs	3 – optoisolated 5 … 24 VDC PNP (2 with analog output)
Serial ports	RS485, RS232
Baud rate	1200, 2400, 4800, 9600, 19200, 38400, 115200
Humidity (non condensing)	85 %
Storage temperature	–30 … +80 °C
Working temperature	–20 … +60 °C
Optoisolated analog output (optional), 16 bit – 65535 divisions	0 … 20 mA; 4 … 20 mA (max. 300 Ω); 0 … 10 V; 0 … 5 V; ± 10 V; ± 5 V (min. 10 kΩ)

6.1 UL version

For the UL version the source states instead: relay outputs 5 – max. 30 VAC, 60 VDC; 150 mA (4 with analog output); working temperature –20 ... +50 °C. Equipment to be powered by 12–24 VDC LPS or Class 2 power source.

7 Electrical connections

7.1 Basic information

– It is recommended that the power supply negative pole be grounded (version D: connect the earthing system to the dedicated external terminal).
– It is possible to supply up to eight 350 Ω load cells or sixteen 700 Ω load cells.
– For 4-wire load cells, make a jumper between EX– and REF– and between EX+ and REF+ (section 7.4).
– Connect terminal –SUPPLY to the RS485 common of the connected instruments in the event that these receive alternating current input or that they have an optoisolated RS485.
– In an RS485 network with several devices, provide a 120 Ω termination resistance on the two devices located at the ends of the network (section 15.3).
– Option E/EC: selects the first 12 formulas (section 7.5).

7.2 Outputs, inputs and power supply

– 5 outputs with fixed function: PRESET, SET, CYCLE END, ALARM, TOLERANCE (chapter 12).
– 3 inputs: START, STOP and input 3, selectable as APPROVAL, SEMI-AUTOMATIC ZERO (default) or NET/GROSS WEIGHT (chapter 12).
– With the analog output (option) input 3, the TOLERANCE output and the E/EC option are no longer available.

Caution Connect the power supply specified on the plate on the back of the instrument. In the 115 V and 230 V versions, terminals +SUPPLY and –SUPPLY generate a continuous voltage of 24 VDC, only to be used as power supply for the instrument inputs.

7.3 Terminals of versions P, Q and X

Terminal	Signal
1	–
2	INPUT No. 3: selectable (+VDC min. 5 V, max. 24 V) · otherwise: +ANALOG OUTPUT (0 ... 20 or 4 ... 20 mA)
3	OUTPUT No. 5: TOLERANCE · otherwise: +ANALOG OUTPUT (0 ... 10 V)
4	E/EC OPTION · otherwise: –ANALOG OUTPUT COMMON
5	RS485: –
6	RS485: +
7	+SUPPLY (12/24 VDC) · 115/230 VAC version: +OUTPUT (24 VDC)*
8	–SUPPLY (12/24 VDC) · RS232, RS485: SHIELD, GND · E/EC OPTION: GND · 115/230 VAC version: –OUTPUT (24 VDC)*
9	RS232: TXD
10	RS232: RXD
11	OUTPUT No. 1: PRESET
12	OUTPUT No. 2: SET
13	OUTPUT No. 3: CYCLE END
14	OUTPUT No. 4: ALARM
15	OUTPUT COMMON
16	INPUT No. 1: START (+VDC min. 5 V, max. 24 V)
17	INPUT No. 2: STOP (+VDC min. 5 V, max. 24 V)
18	INPUT COMMON (–VDC 0 V)
19	–LOAD CELL EXCITATION (–Exc) · LOAD CELL SHIELD
20	+LOAD CELL EXCITATION (+Exc)
21	+LOAD CELL REF/SENSE
22	–LOAD CELL REF/SENSE
23	–LOAD CELL SIGNAL (–Sig)
24	+LOAD CELL SIGNAL (+Sig)

Terminal	Signal
L · N · earth	PHASE · NEUTRAL · GROUND (115/230 VAC version)

*) Use only as power supply for instrument inputs. Terminal 1 has no signal in the source legend.

Note To access the terminal strip on the versions with cable glands, remove the bottom of the instrument by unscrewing the six screws.

7.4 4-wire load cell

With a 4-wire load cell, jumper EX– with REF– (terminals 19 and 22) and EX+ with REF+ (terminals 20 and 21). Without these jumpers the instrument reports **ERCEL** (chapter 22).

7.5 E/EC option

With the E option (buttons, not included in the supply) or the EC option (selector switch) one of the first 12 formulas is selected; the selected formula is started via the START input (section 20.2). Connection to terminal 4 (E/EC OPTION) and terminal 8 (GND). With the analog output the option is not available.

7.6 Connectors of version D

Connector	Pin	Signal	Internal terminal	Internal colour
P1 power supply	–	+SUPPLY (12/24 VDC)	7	red
P1 power supply	–	–SUPPLY (12/24 VDC)	8	black
D1 female, load cell	1	–LOAD CELL EXCITATION (–Exc)	19	black
	2	–LOAD CELL REF/SENSE	22	yellow
	5	LOAD CELL SHIELD	19	–
	6	+LOAD CELL EXCITATION (+Exc)	20	red
	7	+LOAD CELL REF/SENSE	21	blue
	8	–LOAD CELL SIGNAL (–Sig)	23	white
	9	+LOAD CELL SIGNAL (+Sig)	24	green
D3 male, I/O, analog output, E/EC option	1	OUTPUT No. 1: PRESET (max. 24 V)	11	yellow
	2	OUTPUT No. 2: SET (max. 24 V)	12	blue
	3	OUTPUT No. 3: CYCLE END (max. 24 V)	13	white
	4	OUTPUT No. 4: ALARM (max. 24 V)	14	green
	5	OUTPUT No. 5: TOLERANCE (max. 24 V) · otherwise: +ANALOG OUTPUT (0 ... 10 V)	3	orange
	6	OUTPUT COMMON (max. 24 V)	15	purple
	7	INPUT No. 1: START (+VDC min. 5 V, max. 24 V)	16	grey
	8	INPUT No. 2: STOP (+VDC min. 5 V, max. 24 V)	17	pink
	9	INPUT No. 3: selectable (+VDC min. 5 V, max. 24 V) · otherwise: +ANALOG OUTPUT (0 ... 20 or 4 ... 20 mA)	2	brown
	10	INPUT COMMON (–VDC 0 V)	18	white/blue
	11	E/EC OPTION · otherwise: –ANALOG OUTPUT COMMON	4	red
	12	E/EC OPTION: GND · ANALOG OUTPUT: SHIELD	8	black
D4 male, RS232 serial port	2	RS232: RXD	10	yellow
	3	RS232: TXD	9	blue
	5	RS232: SHIELD, GND	8	black
D5 male, RS485 serial port with 24 VDC output	1	+OUTPUT (24 VDC)**	7	red
	2	–OUTPUT (24 VDC)**	8	black
	4	RS485: +	6	yellow
	5	RS485: SHIELD, GND	8	black
	6	RS485: –	5	blue
	7	RS485: –	5	blue
	9	RS485: +	6	yellow

Pins not listed have no signal in the source (D1: 3, 4; D3: 13 ... 15; D4: 1, 4, 6 ... 9; D5: 3, 8). **) Not available if the instrument is battery powered; use only if the instrument is connected to the provided 24 VDC power supply; maximum load 5 W.

7.7 Changing voltage 115/230 VAC

Applies to versions P, Q and X with the 115/230 VAC option (not to version D).

Access the instrument board by removing the six bottom screws and work on the welding side: join the marked points using a stiff wire – for 230 VAC one bridge at the position marked 230, for 115 VAC one bridge at each of the two positions marked 115.

8 Keys, display and menu map

8.1 Keys

Key	Short press	Long press (3 s)	Into menus
[ON/OFF]	power-on	power-off	–
[ESC] (>0<)	semi-automatic zero	tare resetting	cancel or return to previous menu
[TARE] (left arrow)	gross › net	net › gross	select figure to be modified or go to previous menu item
[START] (START/STOP)	batching start / stop	–	–
[PRINT] (up arrow)	print menu	mV load cell test	modify selected figure or go to next menu item
[ENTER] (MENU/ENTER)	setting formulas and batching constants	formula selection for START input (EC not present)	confirm or enter in submenu
[ENTER]+[ESC]	setting general parameters (press [ENTER] immediately followed by [ESC])	–	–
[ENTER]+[TARE]	setting preset tare (press [ENTER] immediately followed by [TARE])	–	–

8.2 Symbols of the LCD display

No.	Marking	Function
–	LED POWER	power supply available
1	PT	preset tare enabled
2	G	gross weight
3	NET	net weight (semi-automatic tare or preset tare)
4	stability symbol	stability
5	>0<	zero (deviation from zero not more than ± 0.25 divisions)
6	PEAK	not used
7	AUTO	batching in progress
8	asterisk	value displayed is not a weight
9	M (box)	not used
10	M (box, crossed out)	not used
11	COEFF	not used
12	HR	not used
13	t · kg · lb · pcs	unit of measure reading
14	IN 1 2 3	the number displayed indicates that the corresponding input is closed
15	OUT 1 2 3 4 5	the number displayed indicates that the corresponding output is closed
16	W1 W2 W3	not used

The numbers are those of the symbol map of the source. Into menus symbol 8 is on to indicate that no weight is displayed.

8.3 Formulas and batching constants menu

Menu **000000** › **[ENTER]** › **FOrP**

[ENTER] opens the menu at **FOrP**; [TARE] [PRINT] scroll to the other main items:

Main item	Sub-items	Chapter
FOrP	**FOrP01** … › **PrESEt SEt**	18.1
CAnCFO	**FOrP00** … › **SUrE**	18.2
tOtAL*	**123456** › **01.10.10** › **COn 1** …	21.1
CAnCtO*	**SUrE**	21.2
COnSt	**MIn MASS tSIC tIMEAt tnCOMP tnLOAd tnUnLO MOdFAL FALdIv FALL tOL SLOU SLOUOn SLOUOF AtArE tIMEtA StAbtA tOtAL PrInt nCOPY PC SLAvE rALArM rtOLEr**	17

*) It appears only if **tOtAL** = **YES** is set in the constants.

8.4 System parameters menu

[ENTER]+[ESC] opens **CALIb**; [TARE] [PRINT] scroll to the other main items, [ENTER] opens the submenu. Into menus changes are applied right after pressing [ENTER].

Main item	Sub-items	Chapter
CALIb	**FS-tEO SEnSIb dIUIS ZErO IMP 0 UEIGHt vnIt**	10
FILtEr	value 0 … 9, then **ANTpOn** / **AntPOF**	11
PArA 0	**0 SEt AUtO 0 trAC 0**	11
AnALOG (option)	**tYPE MOdE AnA 0 AnA FS COr 0 COr FS**	14
SErIAL	**rS485** / **rS232** › **nOnE ModbUS rIP HDrIP HdrIPn YHL PrIntr UEIMOD UEIrIP** › **bAUd Addr dELAY PArItY StOP**	15
ALArM	**COnS EMPtY MASFOr tArE LOAd UnLOAd FALL SLAvE**	12
Ovt-In	**In 3**	12
EnErGY	**bLIGHt**	16
tESt	**In Ovt AnALOG** (option) **EC** (option) **MU-CEL**	12
dAtE	date and time	16
PSUBLC	unlock password	24
SEttIn	**nEXt P PSS EndnEt bLACH**	16
InFO	**GEnrIC OPZ**	16

Direct access from the weight display: [ESC] 3 s › **ZErO** (tare weight zero setting); [PRINT] 3 s › **MU-CEL** (mV test); [ENTER]+[TARE] › **P-tArE** (preset tare).

9 Instrument commissioning

Turn the instrument on with [ON/OFF]. To turn it off press [ON/OFF] for about 3 seconds: when **OFF** appears, release the key. After a blackout the instrument does not come on again automatically (remedy: section 5.5).

Upon switch-on, the display shows in sequence:

- **111111** › **999999** (only in case of approved program);
- instrument model (**UdSK**);
- **SU** followed by the software code (e.g. **SU 5**);
- program type: **LOAd** (load);
- **r** followed by the software version (e.g. **r 1.12.00**);
- **HU** followed by the hardware code (e.g. **HU 104**);
- serial number (e.g. **100515**).

Check that the display shows the weight and that the weight increases when the load cells are loaded. If not, check the connections and the correct positioning of the load cells.

- Instrument already theoretically calibrated (plant identification tag on the instrument and on the cover, load cell rated data entered): reset to zero (section 10.3), then check the calibration with sample weights and correct the indicated weight if necessary (section 10.5).

– Instrument not calibrated (no plant identification tag): load cell data unknown – real calibration (section 10.5); known – theoretical calibration (section 10.2); then reset to zero (section 10.3) and check with sample weights (section 10.5).
– Analog output: set type and full scale (chapter 14).
– Serial communication: set the parameters (chapter 15).
– Set the clock to the current date and time (section 16.2).

Required settings for the first batching:

– in the batching constants menu set the minimum weight (section 17.1);
– in the system parameters menu set the **PSS** parameter (section 16.3);
– in the formulas menu set formula 01 (section 18.1);
– start the batching with [START] or by closing the START contact (chapter 20).

10 Calibration and weight parameters

10.1 Programming of system parameters

From the weight display, press [ENTER] immediately followed by [ESC]. [ENTER]: enter a menu or confirm the data entry; [PRINT]: modify the displayed figure or menu item; [TARE]: select a new figure or modify the displayed menu item; [ESC]: cancel and return to the previous menu.

10.2 Theoretical calibration

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[ENTER]** › **FS-tEO** › **[ENTER]** › **SEnSIb** › **[ENTER]** › **dIUIS**

This function allows the load cell rated values to be set, in sequence:

– **FS-tEO** (default **dEMO**): system full scale = capacity of one cell × number of cells. Example: 4 cells of 1000 kg › full scale 1000 × 4 = 4000. The instrument is supplied with a theoretical full scale **dEMO**, corresponding to 10000. To restore factory values, set 0 as full scale.
– **SEnSIb** (default 2.00000 mV/V): load cell rated sensitivity; enter the average value of the cells, settable 0.50000 ... 7.00000 mV/V. Example 4 cells with 2.00100, 2.00150, 2.00200, 2.00250 › 2.00175 = (2.00100 + 2.00150 + 2.00200 + 2.00250) / 4.
– **dIUIS**: division (resolution), the minimum weight increment which can be displayed. It is calculated automatically after the calibration to 1/10000 of full scale; it can be changed between 0.0001 and 100 with x1 x2 x5 x10 increments.

Important By modifying full scale or sensitivity, the real calibration is cancelled and only the theoretical calibration is valid. If theoretical full scale and the full scale recalculated in real calibration are equal, the theoretical calibration is in use, otherwise the real one. By modifying the theoretical full scale, all parameters containing a weight value are set to default.

10.3 Tare weight zero setting

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[ENTER]** › **FS-tEO** › **[TARE] [PRINT]** › **ZErO**

This menu may also be accessed directly from the weight display by holding [ESC] for 3 seconds. Perform it after the theoretical calibration. Use it to set to zero the weight of the empty system after commissioning and later to compensate zero variations due to product residues.

– Confirm **ZErO** with [ENTER]; the weight value to be set to zero is displayed, all LEDs are flashing.
– Confirm again: the weight is set to zero and stored to the permanent memory.
– Press [PRINT] to display the total weight reset by the instrument, the sum of all previous zero settings.

10.4 Zero value manual entry

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[ENTER]** › **FS-tEO** › **[TARE] [PRINT]** › **IMP 0**

Caution Perform this procedure only if it is not possible to reset the weighed structure tare, for example because it contains product that cannot be unloaded.

Set the estimated zero value (–999999 ... 999999; default 0).

10.5 Real calibration (with sample weights)

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[ENTER]** › **FS-tEO** › **[TARE] [PRINT]** › **UEIGHt**

After the theoretical calibration and the tare weight zero setting, calibrate with weights of known value and correct the display if necessary. Load a sample weight of at least 50 % of the maximum quantity to be weighed. Confirming **UEIGHt**, the current weight is displayed flashing, all LEDs are off; adjust the value with the arrow keys if necessary and confirm – the new weight appears with all LEDs flashing. After a further confirmation **UEIGHt** is shown again; pressing [ESC] repeatedly returns to the weight display.

Example: system of maximum capacity 1000 kg and 1 kg division, sample weights of 500 kg and 300 kg. Load both and correct the indicated weight to 800. Remove the 300 kg weight – the system must show 500; remove the 500 kg weight too – the system must read zero. If not, a mechanical problem affects the linearity; correct it before repeating the procedure.

Important If the correction changes the previous full scale by more than 20 %, all parameters with settable weight values are reset to default.

Linearisation on max. 8 points: repeat the procedure with up to eight different sample weights. It ends with [ESC] or after the eighth value; then only a new real calibration is possible (return to the weight display and re-enter the calibration menu). [PRINT] after confirming the sample weight shows the full scale recalculated from the maximum sample weight entered and the sensitivity **SEnSIb**.

10.6 Units of measure

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[ENTER]** › **FS-tEO** › **[TARE] [PRINT]** › **vnIt**

Display	Unit
kILOG	kilograms
G	grams
t	tons
LB	pounds
Neuton	newtons
LItre	litres
Bar	bars
Atm	atmospheres
PIECe	pieces
NEU-M	newton metres
KILO-m	kilogram metres
OTHER	other unit not included in the list

If the print function is enabled, the symbol of the selected unit is printed after the measured value.

11 Filter on the weight and zero parameters

11.1 Filter on the weight

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **FILtEr**

The filter stabilises the weight display; a higher value increases the effect (0 ... 9, default 4). Confirming **FILtEr** shows the current value; after changing and confirming, the weight is displayed to check its stability. If it is not satisfactory, confirming brings back **FILtEr**. The filter stabilises a weight as long as its variations are shorter than the response time; set it according to the application and the full scale.

Filter value	Response time [ms]	Display and serial port refresh [Hz]
0	12	300
1	150	100
2	260	50
3	425	25
4 (default)	850	12.5
5	1700	12.5
6	2500	12.5
7	4000	10
8	6000	10
9	7000	5

Anti peak

When the weight is stable, the anti peak filter removes sudden disturbances with a maximum duration of 1 second. After the filter value select with [ENTER]: **ANTpOn** enabled (default), **AntPOF** disabled.

11.2 Zero parameters

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **PArA 0**

– **0 SEt** (0 to full scale; default 300; with decimals 300 – 30.0 – 3.00 – 0.300): maximum weight resettable by external contact, keypad or serial protocol.

– **AUtO 0** (0 to 10 % of full scale; default 0): if at switch-on the weight is lower than this value, it is reset; set 0 to disable.

– **trAC 0** (1 ... 5, default **nOnE**): when the weight is stable and after a second deviates from zero by a number of divisions smaller or equal to this value, it is set to zero; **nOnE** disables. Example: **dIUIS** = 5, **trAC 0** = 2 › zero tracking for variations up to 10 (**dIUIS** × **trAC 0**).

12 Outputs, inputs, alarm relay and test

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **Ovt-In** › **[ENTER]** › **In 3**

12.1 Outputs

In the load program the outputs have fixed functions:

– OUTPUT 1: PRESET (for operation see section 16.3);
– OUTPUT 2: SET (for operation see section 16.3);
– OUTPUT 3: CYCLE END (the relay is closed when the cycle end is reached);
– OUTPUT 4: ALARM (the relay is closed when an alarm is present; section 12.3);
– OUTPUT 5: TOLERANCE (the relay is closed when the weight is out of tolerance; section 17.4).

With the optional function OPZWQMC output 5 can be operated as **End tH** instead (section 19.2). With **rALArM** and **rtOLEr** ALARM and TOLERANCE switch on weight instead (section 17.9).

12.2 Inputs

– INPUT 1: START (chapter 20);
– INPUT 2: STOP (section 20.4);

- INPUT 3 (default **ZEr0**), selectable:
  - **ne-LO** (NET/GROSS): closing the input for no more than one second › semi-automatic tare, net display; holding it closed for 3 seconds › back to gross.
  - **ZEr0** (SEMI-AUTOMATIC ZERO): closing the input for no more than one second › the weight is set to zero (section 13.3).
  - **COnS** (APPROVAL): the instrument starts the batching only after verifying that this input is closed.

With the analog output (option) input 3, output 5 (TOLERANCE) and the E/EC option are no longer available.

12.3 Alarm relay closure

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **ALArM**

The ALARM relay closing can be enabled or disabled for each of the following alarms: approval contact (**COnS?**), formula not programmed (**EMPtY**), maximum weight exceeded (**MASFOr**), minimum weight (**tArE?**), no increase in weight (**LOAd**), no decrease in weight (**UnLOAd**), fall (**FALL**), the PC did not read the batching data (**SLAvE**).

- **YES**: in presence of the alarm the relay is closed (default);
- **nO**: the relay is not closed even in the presence of the alarm.

12.4 Test

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **tESt**

Test	Meaning
In	inputs: open input **0**, closed input **1**
Ovt	outputs: **0** › the output must open; **1** › the output must close
EC	E/EC option: the formula selected by the option; without or with inactive option **EC-ER**
AnALOG	analog output option: the signal ranges from minimum to maximum; **MA** current, **VOLT** voltage
MU-CEL	millivolt: load cell response signal in mV with four decimals

13 Tare and zero

13.1 Semi-automatic tare (net/gross)

Close the NET/GROSS input or press [TARE] for less than 3 seconds: the instrument displays the net weight (just set to zero), NET lights up. Back to gross: keep the NET/GROSS input closed or press [TARE] for 3 seconds. The operation can be repeated many times to allow the loading of several products. Example: put the box on the scale, [TARE] – display zero net; introduce the product – display product weight.

- While the net weight is displayed, keep [PRINT] pressed to display the gross weight.
- Not allowed if the gross weight is zero (**InZEr0**).
- The semi-automatic tare is lost upon instrument power-off.

13.2 Preset tare (subtractive tare device)

Menu **000000** › **[ENTER]+[TARE]** › **P-tArE**

A tare value is set manually and subtracted from the display, provided that **P-tArE** ≤ max. weight (**MASS**, section 17.1). The last programmed value is shown; to apply it press [PRINT] and then [ENTER]. Back in the weight display the net weight is shown and NET lights up. To delete and return to gross: hold [TARE] for about 3 seconds or keep the NET/GROSS input closed for 3 seconds; the preset tare is set to zero, NET goes off.

- While the net weight is displayed, keep [PRINT] pressed to display the gross weight.
- If a semi-automatic tare is entered, the preset tare function cannot be accessed.
- If a preset tare is entered, the semi-automatic tare is still possible; the two tares are added.
- Both types of tare are lost when the instrument is turned off.

13.3 Semi-automatic zero

Close the SEMI-AUTOMATIC ZERO input: the weight is set to zero. Or press [ESC] for less than 3 seconds: **STORE?** is displayed for 3 seconds, [ENTER] sets the weight to zero. Only allowed if the weight is lower than **0 SEt** (section 11.2); otherwise **t‾‾‾‾** (upper dashes) appears and the weight is not set to zero.

14 Analog output (option)

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **AnALOG**

– **tYPE**: analog output type: 4 ... 20 mA, 0 ... 20 mA, 0 ... 10 V, 0 ... 5 V, ± 10 V, ± 5 V (default 4 ... 20 mA).

– **MOdE**: **GrOSS** follows the gross weight, **nEt** the net weight, **PLC** remote control via protocol (section 26.6).

– **AnA 0**: weight for the minimum analog output value. Only set a value other than zero to limit the range – e.g. full scale 10000 kg, 4 mA at 5000 kg and 20 mA at 10000 kg › 5000.

– **AnA FS**: weight for the maximum value; it must correspond to the value in the PLC program (default: calibration full scale). Example 4 ... 20 mA with 20 mA = 8000 kg › 8000.

– **COr 0**: zero correction so that the PLC indicates 0; "–" can be set on the last digit on the left. Example: with 4 ... 20 mA the PLC reads 4.1 mA at minimum › set 3.9 to obtain 4.0.

– **COr FS**: full scale correction so that the PLC indicates the value of **AnA FS**. Example: at full scale 19.9 mA › set 20.1 to obtain 20.0.

Caution For the ± 10 V and ± 5 V outputs the soldered jumper SW1 must be closed: open the instrument, locate the soldered jumper SW1 on the analog board mounted perpendicular to the main board and short the pads with a drop of tin.

Analog output type	Minimum	Maximum
0 ... 10 V	–0.150	10.200
0 ... 5 V	–0.150	5.500
± 10 V	–10.300	10.200
± 5 V	–5.500	5.500
0 ... 20 mA	–0.200	22.000
4 ... 20 mA	–0.200	22.000

The output can also be used in the opposite manner: **AnA 0** may be greater than **AnA FS**; the output then increases as the weight decreases. Example 0 ... 10 V with **AnA 0** = 10000 and **AnA FS** = 0: 0 kg › 10 V, 5000 kg › 5 V, 10000 kg › 0 V.

Important All analog outputs are ACTIVE and SINGLE ENDED and can only be connected to PASSIVE receiver devices. Voltage output: minimum load 10 kΩ; current output: maximum load 300 Ω.

15 Serial communication

15.1 Setting

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **SErIAL** › **[ENTER]** › **rS485 / rS232**

First select the port (**rS485** or **rS232**), then the protocol:

Protocol	Meaning
nOnE	no communication (default)
ModbUS	Modbus RTU, addresses 1 ... 99 (chapter 26)
rIP	continuous transmission to remote displays; the remote display shows net or gross weight according to its settings (**bAUd** = **9600**, **PArItY** = **nOnE**, **StOP** = **1**; section 25.1)
HDrIP	as **rIP**, for remote displays with decimal point (section 25.1)
HdrIPn	as **HDrIP**; if the remote display is set to gross and the instrument shows net, the remote display shows net alternated with **nEt**
YHL	continuous weight transmission (section 25.3)
PrIntr	printer
UEIMOD / **UEIrIP**	weight reception (section 15.5)

With the optional function OPZWLAUMAN the **rIPLAU** protocol is added (section 19.3).

15.2 Parameters

Parameter	Meaning
bAUd	transmission speed 1200, 2400, 4800, 9600, 19200, 38400, 115200 (default 9600)
Addr	instrument address 1 … 99 (default 1)
dELAY	delay of the reply 0 … 200 ms (default 0)
PArItY	**nOnE** no parity (default), **Euen** even, **Odd** odd parity
StOP	stop bits 1 or 2 (default 1)
EMPTY	number of blank lines between one printout and the next
HEADER	printing of a custom heading from PC: **YES** / **nO** (default **nO**)
LBLPAR	configuration parameters of the **LBLPRT** label printer (manual of its own)
PrtMOD	connected printer type: **P190**, **STAuP**, **StAUt**, **TMT203**, **LBLPRT**

15.3 RS232 and RS485

Connection	Instrument	Counterpart
RS232 to PC (DB9 female)	RS232 TXD · RS232 RXD · GND	pin 2 · pin 3 · pin 5
RS485, several instruments	RS485 + · RS485 – · GND	RS485 + · RS485 – · GND of each instrument
RS485 directly to RS232 (no converter)	RS485 – · RS485 +	RXD · GND

– Terminals: RS485 – 5, RS485 + 6, GND 8; RS232 TXD 9, RXD 10, GND 8 (version D: connector D5 or D4, section 7.6).

– If the RS485 network exceeds 100 m or baud rates over 9600 are used, connect two 120 Ω terminating resistors between "+" and "–" on the terminal strip of the furthest instruments. With other instruments or converters refer to their manuals.

– A two-wire RS485 output may be used directly on the RS232 input of a PC or remote display; this allows A SINGLE instrument to be used in a ONE WAY mode.

– For an RS485 converter at the PC, follow its wiring diagram.

15.4 Weight reading via serial port

The transmitting instrument is the one connected to the load cell, the receiving instrument the one which receives the weight via RS485 or RS232. Outputs, serial ports and analog output of the receiving instrument work as described, using the weight received.

Caution For this the weight reading mode must be set as **SErIAL** (section 24.5).

15.5 WEIMOD and WEIRIP modes

UEIMOD: the instrument works as if it were directly connected to the load cell; calibration and zero setting are possible. Protocol Modbus, the receiving instrument is master, the transmitting one slave. Transmitting instrument: select the port, **ModbUS**, set the communication parameters and the filter value. Receiving instrument: select the port, **UEIMOD**, the same parameters as on the transmitting one: **bAUd**, **SLAUE** (address of the transmitting instrument, 1 … 99, default 1), **dELAY**, **PArItY**, **StOP**. The transmitting instrument display is locked and shows the instrument model; to unlock it, disconnect the receiving instrument and release the keypad/display lock (section 24.6).

UEIrIP: the instrument receives the gross weight; calibration and zero setting on the transmitting instrument. Transmitting instrument: select the port, **rIP**, set the parameters. Receiving instrument: select the port, **UEIrIP**, **bAUd**, **dELAY**, **PArItY**, **StOP** as on the transmitting one, plus unit **vnIt** and decimals **DECIM** of the received weight; these two items appear in the main menu after setting **UEIrIP**.

UEIMOD and **UEIrIP** can only be enabled on one port; in case of conflict the port set last remains active. Connection transmitting › receiving instrument: RS485 +, RS485 – and –SUPPLY, or RS232 TX › RX, RX › TX and –SUPPLY (terminals section 15.3).

16 Energy saving, date, operation settings and info

16.1 Energy saving

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **EnErGY** › **[ENTER]** › **bLIGHt**

- **On**: back-lighting on;
- **OFF**: back-lighting off;
- **CHAnGE**: back-lighting goes off after about one minute of no activity; pressing a key or a weight change turns it on again.

16.2 Date and time setting

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **dAtE**

Pressing [ENTER] several times scrolls through day, month, year, hours, minutes; [TARE] selects the figure to modify, [PRINT] increases it, [ENTER] confirms and goes to the next item.

16.3 Operation settings

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **SEttIn**

nEXt P: switch conditions from the SET opening to the CYCLE END closing:

- **tIME** (default **YES**): time set in the constants (**tIMEAt**, section 17.2);
- **COMAnd** (default **nO**): START input closure or [ENTER] key pressure;
- **StAbLE** (default **nO**): stable weight.

PSS (default **2**): operating mode of the SET and PRESET contacts:

- **PSS** = **1**: at the batching start only PRESET is closed; once the preset value is reached, PRESET opens and SET closes; once the final set value is reached, SET opens.
- **PSS** = **2**: SET and PRESET close simultaneously at the batching start; once the preset value is reached, PRESET opens (beginning of the slow phase), once the set value is reached, SET opens too. For single-speed batching set **PSS** = **2** and use only the SET contact.
- **PSS** = **3**: at the batching start only PRESET is closed; once the preset value is reached, SET closes too; once the final set value is reached, both are reopened.

EndnEt (default **nO**): display during the CYCLE END phase (unloading of the scale at the end of batching): **YES** net weight, after the CYCLE END opening the gross weight again; **nO** gross weight.

bLACH (default **MAn**): batching resume mode after a power failure: **AUt** (automatic) – at power restore **bLACH** appears for 3 seconds, then the batching resumes from the point of interruption; **MAn** (manual) – **bLACH** appears, [ENTER] resumes, [ESC] stops (section 20.5).

16.4 Info menu

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **InFO**

GEnrIC: identification data of the instrument – **INSTRM** model, **SU COD** software code, **PROGRM** program type, **Fw wer** software version, **ser nV** serial number. **OPZ**: active options.

17 Batching constants

Menu **000000** › **[ENTER]** › **FOrP** › **[TARE] [PRINT]** › **COnSt** › **[ENTER]** › **MIn …**

From the weight display press [ENTER], then press [PRINT] several times until **COnSt** is displayed and confirm. [ENTER]: enter a menu or confirm the data entry; [PRINT]: modify the displayed figure or menu item; [TARE]: select a new figure or modify the displayed menu item; [ESC]: cancel and return to the previous menu.

17.1 Minimum and maximum weight

– **MIn** (0 to full scale; default 10): minimum weight, value at which the scale is considered empty. Batching start is only allowed if the weight is lower; during the unloading phase CYCLE END opens when the weight reaches this value and the safe emptying time is over.

– **MASS** (0 to full scale; default 0): settable and displayable maximum weight. If the displayed weight exceeds it by 9 divisions, ‾‾‾‾‾ (upper dashes) is displayed; if a greater value is set in a formula, **Error** is displayed and the value is not stored. Setting 0 disables the function.

17.2 Times

– **tSIC** safe emptying time (0.0 ... 999.9 s; default 5.0): during the unloading phase (CYCLE END closed) the instrument waits this time after reaching the minimum weight before opening CYCLE END.

– **tIMEAt** waiting time (0.0 ... 999.9 s; default 5.0): time between the SET end of batching and the CYCLE END closing to allow the weight to get steady. It is only required if automatic fall, consumption, printing, tolerance or confirmation from PC is set or the USB or DATIPC option is present.

– **tnCOMP** no comparison time (0.0 ... 999.9 s; default 0.0): after the opening of PRESET the instrument waits this time before comparing the weight with the set value.

– **tnLOAd** no product load time (0.0 ... 999.9 s; default 0.0): if no product is loaded during batching, the instrument activates **LOAd** after this time.

– **tnUnLO** no product unload time (0.0 ... 999.9 s; default 0.0): if no product is extracted during the unloading phase (cycle end), the instrument activates **UnLOAd** after this time. The control is only actuated after the weight has decreased by at least 10 divisions.

17.3 Fall

Fall is the product amount still falling after the batching STOP, which adds to the product already batched. The instrument anticipates the batching STOP to reduce this inaccuracy: AUTOMATIC fall – the instrument calculates it; MANUAL fall – the instrument applies the value set by the operator.

Caution Set the WAITING TIME **tIMEAt** so that the weight is stable at the end of the batching, otherwise the AUTOMATIC fall is not updated correctly.

– **MOdFAL** (default 0): 0 = MANUAL fall; different from 0 (1 ... 99) = AUTOMATIC fall, the value states after how many batchings the fall is updated. Example **MOdFAL** = 3: update every three batching cycles. In cycles without update the WAITING TIME is not applied unless another function requires it (e.g. prints); a high value thus reduces the duration of batchings.

– **FALdIv** (only if **MOdFAL** is different from 0; 0 to full scale; default 0): limit within which the automatic fall is updated according to **MOdFAL**; outside it the instrument updates every cycle. A low value gives more accuracy but may lengthen the batchings. 0 disables. Example **MOdFAL** = 3, **FALdIv** = 5, weight 100: update every batching until the batched weight falls within 95 to 105, then again every 3 batchings.

– **FALL** (0 to maximum weight; default 0): set the fall value for each formula manually (only if **MOdFAL** = 0) or display and modify the value calculated automatically (if **MOdFAL** is different from 0).

17.4 Tolerance

tOL (0 to maximum weight; default 0; for each formula): permitted deviation of the batched weight from the formula value. If the batched weight is lower or higher by more than the tolerance, the instrument closes the TOLERANCE contact; [ENTER] continues the batching. TOLERANCE remains closed until the weight reaches the minimum weight and the safe emptying time has elapsed. Example: SET = 1000, TOLERANCE = 100 › the batched weight must not be lower than 900 or higher than 1100 to allow the instrument to continue the batching. 0 disables the function.

17.5 Slow and tapping function

SLOU (0 to maximum weight; default 0): one value for all formulas in place of the preset value. When the weight reaches the set value minus this value, the slow phase starts by the PRESET contact; if the value is greater than the weight to batch, the whole batching is in slow phase. 0 disables. Example: SET = 100, SLOW = 15 › the slow phase begins at 85.

Tapping function: if the batching device has no slow speed, opening and closing cycles of the SET contact slow down the batching in the final phase and increase the accuracy. Set in **SLOU** the product amount to be batched with the tapping function.

- **SLOUOn** (0 ... 9.9; default 0): time in which SET remains closed during the slow phase; 0 disables.
- **SLOUOF** (0 ... 9.9; default 0): time in which SET remains open during the slow phase; 0 disables.

17.6 Autotare

- **AtArE** (0 ... 999; default 0): automatic tare at batching start; the value states after how many cycles of a batching sequence the autotare is updated; 0 disables. Only possible if the gross weight is lower than the minimum weight **MIn**, otherwise **tArE?** is displayed.
- **tIMEtA** (only if **AtArE** ≠ 0; 0 ... 99.9; default 0): waiting time after the formula start before the autotare is performed and the batching started.
- **StAbtA** (only if **AtArE** ≠ 0; default **nO**): **YES** – zero-setting at batching start after the delay time and only with stable weight; **nO** – right after the delay time.

17.7 Consumption and printing

- **tOtAL** (default **nO**): consumption memory (total batched quantity) for each formula – **YES** enabled, **nO** disabled (chapter 21).
- **PrInt** (default **nO**): print of batching data at cycle end – **YES** enabled, **nO** disabled (chapter 23).
- **nCOPY** (1 ... 9; default 1): number of copies of the batching printout.

17.8 PC

- **PC** (default **nO**): check for a PC connected to the instrument. **YES** – the instrument checks every 10 seconds; if no PC is detected, **PC** is displayed alternated with the weight. Active only with the Modbus protocol.
- **SLAvE** (default **nO**): waiting for confirmation of record batching data from PC. **YES** – the instrument waits for the PC to read the batching data before starting another batching; otherwise **SLAvE** is displayed. **nO** – no waiting.

17.9 ALARM and TOLERANCE relay on weight

- **rALArM** (0 to full scale; default 0): different from 0 – the ALARM contact no longer switches in case of alarm but behaves as a setpoint contact: it closes when the weight reaches this value.
- **rtOLEr** (0 to full scale; default 0): different from 0 – the TOLERANCE contact no longer switches on tolerance but behaves as a setpoint contact: it closes when the weight reaches this value.

18 Formulas

18.1 Formulas programming

Menu **000000** › **[ENTER]** › **FOrP** › **[ENTER]** › **FOrP01 … FOrP99** › **[ENTER]** › **PrESEt / SEt**

Select the formula and set **PrESEt** and **SEt**; up to 99 formulas can be programmed. **PrESEt** is NOT displayed if a slow value (**SLOU**) has been set in the constants. A value higher than the maximum weight **MASS** of the batching constants is rejected with **Error**.

18.2 Deleting formulas

Menu **000000** › **[ENTER]** › **FOrP** › **[TARE] [PRINT]** › **CAnCFO**

Confirm **CAnCFO** with [ENTER]; to delete one formula enter its number, to delete all formulas enter 00 (**FOrP00**); confirm with [ENTER]. You are prompted to confirm (**SUrE**): [ENTER] again deletes, [ESC] cancels.

19 Optional functions

19.1 Enabling optional functions

Optional functions are enabled during program selection (section 24.5); the display shows whether a function is enabled. For the load program the following two exist; they are compatible with each other.

Function	Display enabled	Display disabled
OPZWLAUMAN – batching data on remote displays (section 19.3)	**rpl ON**	**rpl OF**
OPZWQMC* – quantity greater than the scale capacity (section 19.2)	**qmc ON**	**qmc OF**

*) Only available if the approval status **nOtLEG** has been set.

19.2 OPZWQMC – quantity greater than the scale capacity

This function executes a batching sequence where the total quantity to be batched is greater than the scale capacity. The instrument calculates the number of cycles needed and redistributes the remaining quantity in equal shares over the last two cycles.

- **MASS** (0 to max. full scale; default 0): maximum weight that the scale can load (section 17.1); 0 disables the function.
- Output 5 (default TOLERANCE) selectable: **End tH** (END OF PRODUCT TRANSFER – the relay is closed at the end of the last batching cycle) or **tOL** (TOLERANCE).
- Formula programming: [ENTER], **FOrP**, select the formula (e.g. **FOrP01**), then set the total quantity to be batched **tOt Pr**, the preset value **PrESEt** and the set value **SEt**.
- Before starting the batching (chapter 20) a total amount different from the formula can be set besides formula and number of cycles; the next batching proposes the formula value again.
- **Er tOt**: the total quantity set is lower than the one programmed in the formula.

Important If the batching is started from an external contact, the total amount set in the formula is always used.

19.3 OPZWLAUMAN – batching data on remote displays

Several remote displays, connected in parallel to the RS485 serial port, show batching data: remaining quantity to be batched, gross and net weight, state of the instrument or formula and product number. Up to 4 pieces of information, according to the address of the remote display:

Address	Displayed information
A	state of instrument / formula and product being batched / error code
B	remaining quantity of product to be batched
L	gross weight on the scale
N	net weight on the scale

Check compatibility with the transmitted protocol and the possibility of changing the address in the remote display manual. Setting the protocol:

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **SErIAL** › **[ENTER]** › **rS485** › **[ENTER]** › **rIPLAU**

bAUd = **9600**, **PArItY** = **nOnE**, **StOP** = **1**. String: section 25.2.

20 Batching

20.1 Batching sequence

- In case of alarm, the batching may be cancelled with [ESC] or by closing the STOP input.
- With **AtArE** = 0 and **AZErO** = 0 a preset tare or a requested semi-automatic tare is maintained at the start of the batching.

Menu **000000** › **[START]** › **FOr 01** › **[ENTER]** › **C 0001**

After selecting the formula and the desired number of batching cycles, the first cycle starts as follows:

1. The instrument ensures that:
   – the formula has been programmed, otherwise alarm **EMPtY**;
   – the amount of the formula does not exceed the maximum weight **MASS**, otherwise **MASFOr**;
   – input 3 is closed (if set as approval), otherwise **COnS?** – close input 3 to start the batching;
   – the gross weight is lower than the minimum weight **MIn**, otherwise alarm **tArE?** (the start can nevertheless be forced with [ENTER]);
   – only if **tOtAL** = **YES**: if the consumed amount exceeds 999000, **tOtAL** appears for a second; if it exceeds 999999, it is set to zero.
2. The batching starts; PRESET and SET switch according to **PSS** (section 16.3). From now on **PSS** = 2 (default) is assumed: SET and PRESET are closed.
3. If **tnLOAd** is set and the product is not loaded by at least 20 divisions within this time, **LOAd?** is displayed.
4. PRESET opens as soon as it is reached: only if **SLOU** is set – the set value minus the slow value; otherwise the preset value of the formula.
5. If a tapping value has been set, SET opens and closes according to the **SLOUOn** and **SLOUOF** times.
6. Only if **tnCOMP** is set: until the NO COMPARISON TIME has elapsed, the instrument does not verify that the set value is reached.
7. When the set value of the formula minus the possible fall value is reached, SET opens and the product flow is interrupted.
8. After the opening of SET the instrument shows the weight preceded by the letter **A** and waits – only if **tIME** = **YES**: the waiting time **tIMEAt**; only if **COMAnd** = **YES**: closing of the START input or [ENTER]; only if **StAbLE** = **YES**: stable weight.
9. If a tolerance **tOL** is set and the batched quantity is lower than the set quantity minus the tolerance, only one finishing re-start is made (SET closes, back to step 7), otherwise alarm **tOL**. If it is greater than the set amount plus the tolerance, **tOL** appears. [ENTER] cancels the alarm and goes on with the batching.
10. Cycle end phase: CYCLE END closes; the display shows the weight preceded by **E**; only if **PrInt** = **YES** the batching data are printed with date and time; only if **tOtAL** = **YES** the consumption is stored.
11. If **tnUnLO** is set and, after the product extraction has begun, the product is not extracted by at least 20 divisions within this time, **UnLOAd** is displayed.
12. The batching ends (CYCLE END opens) only when the weight is lower than the minimum weight **MIn** and the safe emptying time **tSIC** has elapsed.
13. Only if **SLAvE** = **YES**: the instrument waits for the data recording on PC before being available for a new batching.

If several batching cycles have been set, the instrument starts a new cycle.

20.2 Batching start from external contact

The formula can be selected via an external selector switch (E/EC option, section 7.5). Then close the START contact for at least 0.5 seconds; if the conditions of section 20.1 are met, the selected formula is batched. Without selector switch the latest formula entered via the keypad is batched, or the formula is set as follows: press [ENTER] for 3 seconds, **FESt00** is displayed, set the formula number with the arrow keys and confirm with [ENTER]. With 00 the latest formula set via keypad is recalled.

Important If the START contact is closed at the end of the batching, the same batching sequence is repeated.

20.3 Displaying during batching

During the batching the display shows the weight preceded by the letter **b**. [PRINT] shows the formula number, pressing it again the number of the running cycle.

20.4 Batching stop

– Open the START contact and close the STOP contact to stop the batching. If the START contact is closed, **StArt?** is displayed.

– [START] (STOP) pauses the batching at any time: **PAUSE** is displayed; [ENTER] resumes, pressing [START] again cancels it definitely.

20.5 Resume batching after a power cut

If a blackout occurs during the batching (unloading phase included), **bLACH** appears when power comes back: [ENTER] resumes the batching from the point of interruption, [ESC] cancels it and returns to the weight display. With **bLACH** = **AUt** (section 16.3) the batching resumes automatically after 3 seconds. Power failures do not delete the cycles still to be performed.

21 Consumption

21.1 Displaying consumption

Menu **000000** › **[ENTER]** › **FOrP** › **[TARE] [PRINT]** › **tOtAL** › **[ENTER]** › **123456** › **[ENTER]** › **01.10.10** › **[ENTER]** › **COn 1** …

If consumption is enabled in the constants (**tOtAL** = **YES**), the quantities batched for each formula are stored. Selecting **tOtAL** the following is displayed:

- total quantity consumed for all formulas (divided by 100);
- deletion date;
- quantity consumed for each formula.

The quantities are printed out in full.

21.2 Consumption deletion

Menu **000000** › **[ENTER]** › **FOrP** › **[TARE] [PRINT]** › **CAnCtO** › **[ENTER]** › **SUrE**

Confirm **CAnCtO**; the **SUrE** deletion confirmation is requested: [ENTER] again deletes, [ESC] cancels. If the printer is enabled (chapter 15), an operation receipt is printed.

22 Alarms

Display	Meaning
tArE?	at batching start the weight on the scale is higher than the minimum **MIn**; [ESC] returns to the weight display, [ENTER] cancels the alarm and continues; if the weight comes back below the minimum, the batching starts
COnS?	at batching start the APPROVAL input is open (**In 3** = **COnS**); close the input or cancel with [ESC]
tOL	at batching end the weight differs from the formula value by more than the tolerance; [ENTER] cancels the alarm and continues
FALL	at batching start the fall value is higher than the quantity to be batched; [ESC] cancels alarm and batching
EMPtY	at batching start the formula recalled for running is not programmed; [ESC] quits
MASFOr	at batching start the formula recalled for running exceeds the maximum weight; [ESC] quits
PAUSE	STOP has been pressed during batching; [ENTER] restarts, STOP terminates the batching
bLACH	a power failure occurred during batching; [ESC] cancels, [ENTER] resumes from the point of interruption
LOAd	during the batching the product is not loaded; cancelled automatically if the product increases; STOP twice cancels the batching
UnLOAd	during the unload (CYCLE END closed) the product is not extracted; cancelled automatically if the product decreases; STOP twice cancels the unload
StArt?	3 seconds, if you try to stop the batching (STOP twice or input) while the START input is closed; open START
PArSEr	batching is cancelled; [ESC] quits; if the alarm persists, contact octogon
ErUEIG	weight alarm, the current batching is cancelled; [ESC] back to the weight display, check the alarm
ERCEL	load cell not connected or incorrectly connected; load cell signal exceeds 39 mV; conversion electronics (AD converter) malfunctioning; 4-wire cell without jumpers EX–/REF– and EX+/REF+
NO COM	communication problems between transmitter and receiver; check electrical connections and instrument configuration
ER OL	the weight display exceeds 110 % of full scale
EEROL	weight display on the transmitting instrument exceeds 110 % of full scale
ER AD	internal converter failure; check load cell connections, if necessary contact octogon
‾‾‾‾‾ (upper dashes)	the weight exceeds the maximum weight **MASS** by 9 divisions
ER OF	maximum displayable value exceeded (higher than 999999 or lower than –999999)

Display	Meaning
eErOF	maximum displayable value exceeded on the transmitting instrument
t‾‾‾‾‾ (upper dashes)	weight too high: zero setting not possible
max-pu	in real calibration, after the eighth sample weight has been entered
error	value beyond the permitted values; [ESC] quits the setting leaving the previous value (e.g. too many decimals for the full scale, value above the maximum, sample weight not matching the detected mV increase, analog output correction beyond the limits)
bLOC	lock active on menu item, keypad or display
NODISP	number greater than 999999 or less than –999999, cannot be displayed
BATrtC	buffer battery low, date and time lost; confirm with [ENTER], leave the instrument on for at least 12 hours; if the alarm persists contact octogon
DATE?	incorrect date detected; check and correct it in the **dAtE** menu
COMAnd	waiting for START closure or [ENTER] to continue the batching
PC	the PC is not connected
SLAvE	the PC has not read the batching data
InZErO	gross weight equal to zero: semi-automatic tare not possible

22.1 Serial protocol alarms

Alarm	Modbus RTU, status register	RIP*	HDRIP-N
ERCEL	bit 0	**__0-F_**	**_ERCEL**
ER OL	bit 3	**__0-L_**	**_ER_OL**
ER AD	bit 1	**__0-F_**	**_ER_AD**
‾‾‾‾‾‾ (upper dashes)	bit 2	**__0-L_**	######
ER OF	gross bit 4 · net bit 5	**__0-F_**	**_ER_OF**
t‾‾‾‾‾ (upper dashes)	response to the zero command: 'value not valid' error (code 3)	**__0-F_**	**0__SET**

"_" stands for a space. *) With remote displays on the **rIP** protocol, the display reads ‾‾‾‾‾‾ (upper dashes) if the message exceeds 5 digits.

With an alarm the relays open and the analog outputs go to the lowest possible value:

Range	0 ... 20 mA	4 ... 20 mA	0 ... 5 V	0 ... 10 V	± 10 V	± 5 V
Output value	–0.2 mA	3.5 mA	–0.5 V	–0.5 V	0 V	0 V

23 Printing examples

If the printer has been set (chapter 15), press [PRINT] from the weight display:

- **UEIGHt**: prints the displayed weight;
- **COnSt**: prints the constants (minimum weight, maximum weight, etc.);
- **FOrP**: prints one or all of the formulas – after [ENTER] **FOrP01** is displayed, set the formula number or 00 to print them all;
- **tOtAL**: prints consumption (only if **tOtAL** = **YES**, section 17.7).

"‹Model›" stands for the model identification printed by the instrument.

Batching without tare (AtArE = 0)

```
‹Model›  LOAD     Addr:01
FORMULA:             01
CYCLE:       1/       1
DATE: 01/10/11 08:30:01
INIT.WEIGHT       10 kg
GROSS   1005:   1000 kg
```

Batching with predetermined tare set (AtArE = 0, AZErO = 0)

```
‹Model›  LOAD     Addr:01
FORMULA:             01
CYCLE:       1/       1
DATE: 01/10/11 08:30:01
PT                10 kg
INIT.N             3 kg
NET    1005:    1000 kg
TOT C           1002 kg
```

Batching with manual semi-automatic tare (AtArE = 0, AZErO = 0)

```
‹Model›  LOAD     Addr:01
FORMULA:             01
CYCLE:       1/       1
DATE: 01/10/11 08:30:01
N                 10 kg
INIT.N             3 kg
NET    1005:    1000 kg
TOT C           1002 kg
```

Batching with tare each cycle (AtArE = 1)

```
‹Model›  LOAD     Addr:01
FORMULA:             01
CYCLE:       1/       1
DATE: 01/10/11 08:30:01
TARE              34 kg
NET     1005:   1000 kg
```

Batching with reset every X cycles (AtArE = X)

```
‹Model›  LOAD     Addr:01
FORMULA:             01
CYCLE:       2/       2
DATE: 01/10/11 08:30:01
INIT.WEIGHT         1 kg
GROSS   1070:   1000 kg

‹Model›  LOAD     Addr:01
FORMULA:             01
CYCLE:       1/       2
DATE: 01/10/11 08:30:01
ZERO WEIGHT        12 kg
GROSS   1026:   1000 kg
```

Constants printout

```
‹Model›  LOAD     Addr:01
DATE: 01/10/11 08:30:01
       CONSTANTS
MIN                  10
MASS                  0
TIME SIC            5.0
TIME WAIT           0.0
TIME NCOMP          0.0
TIME NLOAD          0.0
TIME NUNLOAD        0.0
FALL              MANUAL
SLOW                  0
TIME SLOWON         0.0
TIME SLOWOF         0.0
PSS                   2
AUTOTARE             NO
UNLOAD             GROSS
TOTAL                NO
PRINT                NO
PC                   NO
SLAVE                NO
BLACKOUT          MANUAL
RELAY ALARM           0
RELAY TOL.            0
FOR.      FALL    TOLER
05           0      100
48         178        0
```

Standard formula printout (SLOU = 0)

```
‹Model›  LOAD     Addr:01
DATE: 01/10/11 08:30:01
FORMULA:             02
SET              2000 kg
PSET              200 kg
```

Formula with slow active printout (SLOU = 100)

```
‹Model›  LOAD     Addr:01
DATE: 01/10/11 08:30:01
FORMULA:             02
SET              2000 kg
SLOW              100 kg
```

Consumption printout

```
‹Model›  LOAD     Addr:01
DATE: 01/10/11 08:30:38
      CONSUMPTION
F01              1148 kg
F03              1456 kg
TOTAL            2604 kg
FROM: 01/09/11 09:11:13
```

Weight printout

```
‹Model›  LOAD     Addr:01
DATE: 12/09/11 14:48:12
GROSS            1204 kg
NET               831 kg
TARE              373 kg
```

If consumption is set to zero, "CONSUMPTION ERASED" is printed as well.

24 Reserved for the installer

24.1 Menu locking

Any menu can be locked. Select the menu (e.g. **CALIb**) and press [ESC] and [TARE] simultaneously for 3 seconds: the display shows **C.ALIb** (the left point indicates the lock). When the operator tries to enter this menu, **bLOC** is displayed.

24.2 Menu unlocking

With **C.ALIb** displayed press [ENTER] and [PRINT] simultaneously for 3 seconds; the unlock password is requested (if enabled) and the display shows **CALIb** without point.

24.3 Temporary menu unlocking

With **C.ALIb** displayed press [PRINT] and [TARE] simultaneously for 3 seconds; after the password (if enabled) all menus, including the locked ones, can be entered and modified. Returning to the weight display restores the lock.

24.4 Setting unlock password

Menu **000000** › **[ENTER]+[ESC]** › **CALIb** › **[TARE] [PRINT]** › **PSUBLC**

The password must contain 6 characters; to change a customized password the current one is required. **000000** (default) disables the unlock password.

24.5 Data deletion and program selection

Caution Perform these operations only after contacting octogon. After each operation **DONE** is displayed, press [ENTER] to continue; [ESC] cancels without changes.

Upon power-on hold [ESC] until **PROG** is displayed, then:

– Constants restore (the calibration is not erased): confirm **PROG**, select **PASSu** with the arrow keys, set code 6935 and confirm.

– Program selection: confirm **PROG** and select **LOAd** with the arrow keys (single product loading program); the other items (**bASE**, **rIP**, **UnLOAd**, **3PrOd**, **6PrOd**, **14PrOd**, **MULtI**) select other programs with manuals of their own.

– Weight reading mode (not with **rIP**): **CELL** – from load cells, intelligent junction box or weight transmitter connected to the instrument; **SErIAL** – via serial port (WEIMOD or WEIRIP, section 15.5).

– Approval status (not with **rIP**): **nOtLEG** not approved; **LEGAL** approved, single interval*; **LEGMI** approved, multi-interval*; **LEGMR** approved, multiple range*.

– Active regulation (not with **nOtLEG**): **OIML**, **NTEP**, **INMETR** (**bASE** program only).

– Connection of an intelligent junction box or weight transmitter (not with **SErIAL** or **rIP**): **EStYES** connected, **EStnO** not connected.

– Enabling the optional functions (not with **bASE** or **rIP**; chapter 19).

*) For the approved version request the proper manual and procedure from octogon, stating hardware code and serial number (chapter 9). When the indicator is used with an intelligent junction box or weight transmitter, the approval status set on both devices must be the same. By confirming, the instrument is restored to default and data is erased.

24.6 Keypad or display locking

Press [ESC] immediately followed by [PRINT] and hold them down for about 5 seconds (also possible via the Modbus protocol, section 26.5):

– **FREE**: no lock;

– **KEY**: keypad lock – when a key is pressed **bLOC** is displayed for 3 seconds;

– **DISP**: keypad and display lock – the display shows the instrument model instead of the weight; when a key is pressed **bLOC** is displayed for 3 seconds.

25 Continuous transmission protocols

Common to all strings: with negative weight the first character from the left is "–" (ASCII 45); in case of error or alarm the weight is replaced by the messages of section 22.1. The checksum ckck is the XOR of the 8-bit ASCII codes of the characters between "&" and "\" (both excluded), as two hexadecimal digits 0 … 9, A … F in ASCII.

25.1 Continuous transmission to remote displays

The string is transmitted 10 times per second; **bAUd** = **9600**, **PArItY** = **nOnE**, **StOP** = **1**. **rIP**: remote displays e.g. octogon EDLD; **HDrIP** and **HdrIPn**: remote displays e.g. octogon EDLF, EDLG.

```
&NxxxxxxLyyyyyy\ckckCR
```

Character	Meaning
&	start (ASCII 38)
N	net weight identification (ASCII 78)
xxxxxx	6 characters of net weight or PEAK if present (ASCII 48 … 57)
L	gross weight identification (ASCII 76)
yyyyyy	6 characters of gross weight (ASCII 48 … 57)
\	separation (ASCII 92)
ckck	2 checksum characters
CR	end (ASCII 13)

– **HDrIP**: the decimal point at the position shown on the instrument display can also be transmitted; if the value exceeds 5 digits, only the 5 most significant digits are transmitted, if negative no more than the 4 most significant; the decimal point shifts accordingly.

– **HdrIPn**: in addition the instrument transmits **nEt** every 4 seconds in the gross weight field if a net operation has been carried out.

– Below –99999 "–" is sent alternated with the most significant figure.

25.2 Batching data to remote displays (OPZWLAUMAN)

With the optional function OPZWLAUMAN and the **rIPLAU** protocol (section 19.3) the instrument sends to the remote displays connected in parallel:

```
&AsxxxxxBsyyyyy\ckckCR
```

Character	Meaning
&	start (ASCII 38)
A, B	1 remote display identification character each (A, B, L, N)
s	minus sign "-" or other character with a decimal point "."
xxxxx, yyyyy	5 alphanumeric characters each (may include ".")
\	separation (ASCII 92)
ckck	2 checksum characters
CR	end (ASCII 13)

25.3 Continuous transmission YHL

The string is transmitted 5 times per second; after a net operation the net weight, otherwise the gross weight.

```
=xxxxxxxxx
```

Character	Meaning
=	start (ASCII 62)
xxxxxxxx	9 characters of net or gross weight (ASCII 48 ... 57), LITTLE ENDIAN sorting

With negative weight the first character from the right is "–"; the decimal point is transmitted at the position given by the calibration. Example gross weight –20.7 kg: **`=7.02000-`**. In case of error or alarm "999999999" is sent.

26 Modbus RTU protocol

The Modbus RTU protocol allows the reading and writing of the registers listed below according to the Modicon PI-MBUS-300 specification. Selection: section 15.1. Check whether the Modbus master (or the development tool) numbers the registers from 40001 or from 0; in the second case the register is the table value minus 40001 (e.g. 40028 › 27).

Some data are written directly to the EEPROM, whose writing operations are limited (100000); avoid useless writings. The instrument does not write if the value equals the stored one. Numbers without prefix are decimal, with 0x hexadecimal.

26.1 Data format and functions

1 start bit; 8 data bits, least significant bit sent first; settable parity bit and stop bit. Use only the following functions – others could be incorrectly interpreted and generate errors or blocks of the system:

Function	Description
03 (0x03)	READ HOLDING REGISTER (read programmable registers)
16 (0x10)	PRESET MULTIPLE REGISTERS (write multiple registers)

The interrogation frequency depends on the baud rate (the instrument stands by for at least 3 bytes before calculating a response); **dELAY** (section 15.2) adds a further delay.

	Address	Function	Content	CRC	Bytes
Function 3 query	A	0x03	1st register 0x0000 · no. registers 0x0002	2 byte	8
Function 3 response	A	0x03	no. bytes 0x04 · 1st register 0x0064 · 2nd register 0x00C8	2 byte	3 + 2 × no. registers + 2
Function 16 query	A	0x10	1st register 0x0000 · no. registers 0x0002 · no. bytes 0x04 · value 1 0x0000 · value 2 0x0000	2 byte	7 + 2 × no. registers + 2
Function 16 response	A	0x10	1st register 0x0000 · no. registers 0x0002	2 byte	8

26.2 Broadcast requests and communication errors

- Broadcast (address 0): read requests are not executed and not answered; write requests are executed but not answered.
- The strings are checked by CRC. In case of communication error the slave does not respond; the master must consider a time-out.

– If a correctly received string is not executable, the slave responds with an exceptional response: address, function + 0x80, code, CRC – code 1 ILLEGAL FUNCTION (function not valid or not supported), 2 ILLEGAL DATA ADDRESS (data address not available), 3 ILLEGAL DATA VALUE (invalid value).

26.3 List of available registers

A maximum of 32 registers per query or response. R = read only, R/W = read and write; H/L = high/low half of the DOUBLE WORD. Listed are the registers that apply to the load program.

Register	Description	EEPROM	Access
40001	firmware version	–	R
40002	instrument type	–	R
40003	year of manufacture	–	R
40004	serial number	–	R
40005	program type	–	R
40006	command register (section 26.5)	no	R/W
40007	status register (section 26.4)	–	R
40008 / 40009	gross weight H / L	–	R
40010 / 40011	net weight H / L	–	R
40012 / 40013	peak weight H / L	–	R
40014	divisions and units of measure (section 26.4)	–	R
40017	inputs	–	R
40018	outputs	no	R
40050	instrument status (section 26.4)	–	R
40051 ... 40060	register 1 ... 10 (exchange registers)	no	R/W
40065 / 40066	sample weight for instrument calibration H / L (with command 101)	–	R/W
40067 / 40068	weight value corresponding to zero of the analog output H / L	yes	R/W
40069 / 40070	weight value corresponding to full scale of the analog output H / L	yes	R/W
40073 / 40074	preset tare H / L (with command 130)	–	R/W

26.4 Status, inputs, outputs, divisions

Status register 40007	Meaning
Bit 0	load cell error
Bit 1	AD converter malfunction
Bit 2	maximum weight exceeded by 9 divisions
Bit 3	gross weight higher than 110 % of full scale
Bit 4	gross weight beyond 999999 or less than –999999
Bit 5	net weight beyond 999999 or less than –999999
Bit 7	gross weight negative sign
Bit 8	net weight negative sign
Bit 9	peak weight negative sign
Bit 10	net display mode
Bit 11	weight stability
Bit 12	weight within ± ¼ of a division around zero

Instrument status 40050	Meaning (load program)
0	instrument in idle condition (weight displaying)
1	formulas displaying
2	batching constants displaying
3	consumption displaying
4	system parameters displaying
5	setting of formula number and cycles to batch
6	instrument in batching condition
7	**EMPtY** alarm
8	‾‾‾‾‾‾ (upper dashes) alarm
9	**COnS?** alarm
10	**tArE?** alarm
11	**LOAd** alarm
12	phase elapsing between the opening of SET and the closing of CYCLE END
13	batching pause
14	cycle end
15	**UnLOAd** alarm
16	**bLACH** alarm
18	**FALL** alarm
25	**tOL** alarm
26	instrument waits for the printing to complete
27	operating menu displaying
30	**USb Er** alarm (only with DATAUSB option)
33	**ErUEIG** alarm
34 / 35	**MEMFUL** / **MEMOUr** alarm (only with DATAUSB or DATAPC option)
38	the operator is starting an automatic batching
39	the operator is starting a manual batching
40	**SLAvE** alarm

The other values of 40050 belong to other programs. Inputs 40017: bit 0 ... 2 = input 1 ... 3. Outputs 40018: bit 0 ... 4 = output 1 ... 5; read only in the load program.

Register 40014: L byte = division, H byte = unit of measure.

L byte	Divisor	Decimals	H byte	Unit
0	100	0	0	kilograms
1	50	0	1	grams
2	20	0	2	tons
3	10	0	3	pounds
4	5	0	4	newton
5	2	0	5	litres
6	1	0	6	bar
7	0.5	1	7	atmospheres
8	0.2	1	8	pieces
9	0.1	1	9	newton metres
10	0.05	2	10	kilogram metres
11	0.02	2	11	other
12	0.01	2		
13	0.005	3		
14	0.002	3		
15	0.001	3		
16	0.0005	4		
17	0.0002	4		
18	0.0001	4		

26.5 Commands to the command register 40006

Command	Description
0	no command
7	semi-automatic tare enabling (net weight displaying)
8	semi-automatic zero
9	semi-automatic tare disabling (gross weight displaying)
21	keypad lock
22	keypad and display unlock
23	keypad and display lock
99	save data in EEPROM
100	tare weight zero setting for calibration
101	save first sample weight for calibration
104	real calibration cancellation
106	add sample weight for calibration
130	preset tare enabling
131	reserved
201	batching: START
202	batching: PAUSE
203	batching: RESUMES from PAUSE
204	batching: STOP
205*	batching: accepts alarm and stop
206*	batching: ignores the alarm **tArE?**
207*	batching: ignores the alarm **tOL**
209	batching: continues when the message **COMAnd** appears or if INSTRUMENT STATUS = 12 (only if **COMAnd** = **YES**)
250	confirmation of batching data reading
2000 ... 2999	constants and formulas (section 26.8)
6811 / 6812	writing / reading the current value requested at the analog output
6813 / 6814	writing / reading the voltage value requested at the analog output

*) In case of alarm signals during the batching, command 205 accepts the alarm and stops the batching; with the **tOL** alarm command 207, with the **tArE?** alarm command 206 continues the batching. To execute the same command twice consecutively, send command 0 between them.

26.6 Analog output

– **MOdE** = **GrOSS** or **nEt** (chapter 14): write or read the weight for zero and full scale in registers 40067/40068 and 40069/40070.

– **MOdE** = **PLC**: the output is set directly. Multiply the value by 10000, write the H bytes into REGISTER 1 (40051) and the L bytes into REGISTER 2 (40052) and send command 6811 (current, value in mA) or 6813 (voltage, value in V). Reading: send command 6812 or 6814, read 40051/40052 and divide by 10000.

Example	REGISTER 1 (H)	REGISTER 2 (L)	Total
write current 14 mA, hexadecimal	0x0002	0x22E0	0x000222E0
decimal	2	8928	140000
read voltage, hexadecimal	0x0000	0xCF76	0x0000CF76
decimal	0	53110	53110 › 5.3110 V

26.7 Real calibration commands

– Unload the system and reset the displayed weight with command 100 (tare weight zero setting for calibration).

– Load a sample weight and write its value to registers 40065/40066.

– Command 101 saves the first sample weight and removes the previously saved values; command 106 adds a sample weight and keeps the previous ones.

– Up to 8 different sample weights for a linearisation; the same sample weight only once per calibration, no sample weights of value zero. If successful, 40065/40066 are set to zero.

– Command 104 cancels the real calibration and returns to the theoretical one; the tare reset is not cancelled.

Enter the sample weight in divisions (register 40014): 100 kg with division 0.001 › 100000. 40065/40066 are a 32-bit signed number; negative values in two's complement if necessary: –56 kg › 40065 = 0xFFFF (–1), 40066 = 0xFFC8 (–56).

26.8 Constants and formulas reading and writing

Values are exchanged via the exchange registers 40051 ... 40060 together with the command register (CMD R = reading command, CMD W = writing command; H/L = high/low half of the DOUBLE WORD). Before a reading command set the values marked with *. Example command 2002: write in 40053 the number of the formula whose total set is to be read; send 2002 to the command register 40006; read 40060 continuously until the command echo (here 2002, "data ready") or 0xFFFF ("error in the command") appears; then read 40051 ... 40060 and use them according to the table.

Variable	CMD R	CMD W	Register and content
Formulas programming	2000	2001	40051 quantity H · 40052 quantity L · 40053* 1 = set, 2 = preset · 40054* 1 = set, 2 = preset · 40055* formula no.
Total set by formula (OPZWQMC option)	2002	2003	40051 quantity H · 40052 quantity L · 40053* formula no.
Totals management	2020	–	40051 quantity H · 40052 quantity L · 40053* formula no. · 40054* 1 = consumption
Totals deletion date and time	2022	–	40051 day · 40052 month · 40053 year · 40054 hours · 40055 minutes · 40056 seconds · 40057* 1 = consumption
Formula no. and cycles no. to run	2030	2031	40051 formula no. · 40052 cycles H · 40053 cycles L
Current cycle	2032	–	40051 cycle H · 40052 cycle L · 40053 step H · 40054 step L · 40055 product H · 40056 product L · 40057 set H · 40058 set L
Batching data reading	2100	–	section 26.10

26.9 Writing and reading formulas, batching start and stop

– Writing a formula: write the quantity to be batched in 40051 and 40052, the value 1 for SET or 2 for PRESET in 40053 and 40054, the formula number in 40055; send command 2001 to the command register.

– Reading a formula: write the value 1 for SET or 2 for PRESET in 40053 and 40054, the formula number in 40055; send command 2000; read 40060 until it differs from 2000 (command echo) or shows 0xFFFF (command error); after the echo read the quantity of the formula in 40051 and 40052.

– Batching start: write formula and number of cycles in 40051 ... 40053, set them with command 2031; command 201 starts the batching.

– Batching stop: command 204.

26.10 Batching data reading

At the end of the batching the instrument makes the data available. Send command 1114 to the command register and verify that 40051 = 1 (data ready). Unlike the other commands there is no echo here: wait for bit 7 of 40060 to be equal to 1. Then send one of the following queries to the command register and read the values in 40051 ... 40060:

Query	Send	Response in 40051 ... 40060
Batching step	2100, 40051 = step no. (load program: 1)	40051/40052 real batched H/L · 40053/40054 theoretical batched H/L · 40055/40056 alarm H/L · 40057/40058 alibi ID H/L · 40059 product number · 40060 value detail
Initial tare	2100, 40051 = 1005	40051/40052 value H/L · 40055/40056 alarm H/L · 40060 value detail

Value detail 40060: bit 0 = negative value (refers only to the real batched value), bit 7 = data ready. After reading send command 250: the instrument accepts the **SLAvE** alarm and continues the batching sequence.

Batching data alarms (40055, 40056): one byte per alarm, up to 4 alarms in chronological order.

Code	Alarm
0	no alarm
1	general alarm
2	**EMPtY**
3	**MASFOr**
4	**tArE?**
5	**COnS?**
6	**bLACH**
7	**tOL**
8	**LOAd**
9	**UnLOAd**
12	batching STOP
13	**ErUEIG**
14	**FALL**
15	**SLAvE**
24	**Er tOt** (OPZWQMC option)
27	**USb Er** (only with DATAUSB option)
28 / 29	**MEMFUL** / **MEMOUr** (only with DATAUSB or DATAPC option)

26.11 Communication example

Values in hexadecimal with prefix h; instrument address h01. Function 3: read gross weight (4000) and net weight (3000) from 40008 ... 40011.

Query	Response
h01 h03 h00 h07 h00 h04 hF5 hC8	h01 h03 h08 h00 h00 h0F hA0 h00 h00 h0B hB8 h12 h73

Structure: address, function, first register H/L, number of registers H/L, CRC16 L/H; response: address, function, byte count, data, CRC16 L/H. Further CRC16 examples: Modicon PI-MBUS-300.

27 Directives and standards

According to the manufacturer's declarations of conformity (EU and United Kingdom, 12/12/2024):

Directive	Standards
2014/35/EU Low Voltage	EN 61010-1:2010+A1:2019 – not applicable for the VDC type (only for 230/115 VAC type)
2014/30/EU EMC	EN 55011:2016+A1+A11:2020 · EN 61000-6-2:2019 · EN 61000-6-4:2019 · EN 61000-4-2:2009 · EN 61000-4-3:2006+A2:2010 · EN 61000-4-4:2012 · EN 61000-4-5:2014+A1:2017 · EN 61000-4-6:2014
2014/31/EU NAWI (only if the M mark is applied)	EN 45501:2015 · OIML R76-1:2006
United Kingdom	Electrical Equipment (Safety) Regulations 2016, Electromagnetic Compatibility Regulations 2016, Non-automatic Weighing Instruments Regulations 2016 (only if the M mark is applied) – with the corresponding BS EN standards

The declarations of conformity are available from octogon on request.